

Assembly instructions cast-iron bathtub

- For the right assembly 2-3 persons are required.
- Put two wood rods or one soft mattress on the ground before installing, and turn the bathtub on it.
- Pack the feet on the bathtub (Please follow the sketch map) (1).
- Reverse the bathtub to make the leg of bathtub on the ground. Be careful – do not put the bath on 2 feet – you can damage the feet.
- Do not put any tools into the bathtub as you can damage it (2).
- Do not step into the bathtub until fully installed (3).
- Store the bathtub under cover. Protect it during transport and at the job site (4).
- Make sure the bathtub is standing horizontally. Adjust the feet if needed (5).
- Use Silicon to fill the space between bathtub and the wall (6).

RECOMMENDATIONS

- Access to the underside of the bath must be ensured.
- Do not clean with abrasive material nor acids, only with soap and water.
- After every use rinse bath with lukewarm water and dry with a soft cloth. Dry after use.

Инструкция по монтажу чугунной ванны

- Для установки чугунной ванны необходимо 2-3 человека.
- Переверните ванну и положите ее на деревянные рейки или мягкую поверхность (например, матрас).
- Прикрутите ножки на ванну согласно схеме (рис. 1).
- Переверните ванну в правильное положение. Будьте осторожны – НЕЛЬЗЯ опирать ванну на две ножки для избежания их обламывания.
- Не кладите внутрь ванны никаких предметов, инструментов (рис. 2).
- Не вставайте внутрь ванны до окончания процесса установки (рис. 3).
- При установке ванну необходимо закрыть, чтобы исключить возможность повреждения эмалированной поверхности (рис. 4).
- С помощью уровня выставите ванну горизонтально. Если необходимо, отрегулируйте высоту ножек (рис. 5).
- Ванна должна стоять вплотную к стене, примыкание следует тщательно заделать силиконовым герметиком (рис. 6).

РЕКОМЕНДАЦИИ

- Обеспечьте доступ под ванну после установки (лючок доступа или съемный экран под ванну).
- Не используйте для мытья ванны абразивные материалы и средства, содержащие щелочи и кислоты. Протирайте поверхность ванны только водой с мылом.
- Во избежание появления желтых пятен от воды, ванну после использования необходимо ополоснуть теплой водой и насухо вытереть мягкой тряпкой или губкой.
- Стоячая воды или течь воды из смесителя (из-за наличия в воде различных минеральных солей) образует желтый налет на эмали, который практически невозможно удалить.
- Не допускайте падения в ванну твердых предметов.

